


Dealer Service Bulletin #103

Main Menu Titles

Press and Hold the Freewheel & Front Headlight Buttons for approx.. 3-4 seconds to enter the Main Menu



You will know you are in the Main Menu when you see a LARGE "01" on the top left of the LCD screen and a smaller "01" in the bottom left of the screen. The smaller "01" represents the menu page you are on. By pressing the Freewheel Mode you can scroll through the menu pages

"1": Push mode setting

"2": Wheel diameter setting

"3": speed mode option

"4": Voltage profile voltage setting

"5": Cumulative mileage display function selection

"6": Metric - British option

"7": Horn mode selection

"8": Voltage tachometer mode speed compensation setting

"9": Taillight mode selection

"10": Reverse signal delay closing time setting