

Dealer Service Bulletin #104

MP3 Player Voice Off



Prior to installing the MP3 Player Voice Off upgrade you will require a USB Flash Stick that has a capacity of **LESS THAN 8GB** and please read all instructions prior to commencing;

- 1) Copy the upgrade file "jl_690x.bfu" onto a USB flash disk, and also add a music file with MP3 format. **Do NOT** rename this upgrade file ***
- 2) Turn the scooter on, press the lock button on the remote, when LCD shows MP3 mode, insert USB flash disk to the USB-1 port, the scooter will automatically begin the upgrade.
- 3) During the upgrade process, do NOT cut off the power supply or drive the scooter, also do NOT remove the USB flash disk until the process is fully complete or it will result in the device crashing.
- 4) After about 10 seconds, there will be a sound " di di di", it shows upgrade completed, you can then pull out the USB disk, turn off the scooter and turn on again .
- 5) Please don't insert the USB disk with this upgrade file into any other multimedia devices as this file may cause damage to said device.
- 6) It is recommended by the manufacturer that once the upgrade has been completed that you immediately delete the upgrade file from the UBS flash stick to prevent any accidental use.
- 7) **This process can NOT be reversed** – once the Voice Off upgrade has been installed it's there for the life of the Mobility Scooter.

***** You will need to contact our Team to obtain a copy of this file**