




CHARGER






贴纸示意图




贴纸示意图



左右防滑贴纸





Model	LOC	Part #	Description
CHARGER	1	QLSL09P503A3A	Battery top cover
CHARGER	2	QLSL09A501B9C	Side reflector with E-Mark(Yellow)
CHARGER	5	QLSL09P505B19	Battery rear decoration skirt cover(Silver 643C)
CHARGER	6	QLSL09P182A00	Screw
CHARGER	7	QLSL09E504AK0	N/A
CHARGER	7	QLSL09E504AK3	N/A
CHARGER	7-1	QLSL09P509B03	Battery rear cover only(Blue 288C)
CHARGER	7-1	QLSL09P509B15	Battery rear cover only(Red 7645C)
CHARGER	7-2	QLSF03F612AK0	Taillight assembly with turning light
CHARGER	9	QLSJ04P529A8A	Floor mat
CHARGER	10	QLSL09P511A19	Center deck(Silver 643C)
CHARGER	12	QLSL09E502AK0	N/A
CHARGER	12	QLSL09E502AK3	N/A
CHARGER	12-1	QLSL09P501A03	Front deck only(Blue 288C)
CHARGER	12-1	QLSL09P501A15	Front deck only(Red 7645C)
CHARGER	12-2	QLSL09P504A19	Front face decoration cover(Silver 643C)
CHARGER	12-3	QLSK09F617AK0	Headlight assembly
CHARGER	12-4	QLSL09P507AG1	Headlight reflecting base(Silver)
CHARGER	12-5	QLSL09P506A4P	Headlight cover(Transparent)
CHARGER	16	QLSL09E219AK0	Front wheel assembly(air,13")
CHARGER	16-1	QLSH05P217AB4	Outer tire for 13"
CHARGER	16-2	QLSH05P218AB4	Inner tube for 13"
CHARGER	16-3	QLSK09P235AH0	Outside AL mag
CHARGER	16-4	QLSK09P240AG0	Inside steel rim
CHARGER	16-5	QLSK09A218AG0	Front hub
CHARGER	16	QLSL09E234AK0	Front wheel assembly(solid,13")
CHARGER	16-1	QLSF03P232D0A	Solid tire only(13")(F/R)
CHARGER	17	QLSL09E205BK0	Steering arm spindle assembly(R)
CHARGER	19	QLSL09E119AK0	N/A
CHARGER	19-1	QLSL09E117AK0	Front bumper assembly
CHARGER	21	QLSL09E206AK0	Tie rod assembly(L/R)
CHARGER	22	QLSL09A205AG0	Steering tube and plate
CHARGER	25	QLSJ07P145B1G	Front and rear spring(Inside)
CHARGER	26	QLSK08P130A1G	Front and rear spring(Outside)
CHARGER	27	QLSJ07P534A3A	Spring holder
CHARGER	28	QLSL09E204AK0	Steering arm spindle assembly(L)
CHARGER	28-1	QLSL09A203BG0	Steering arm spindle assembly(L)
CHARGER	35	QLSL09E114AK0	Side bumper(L/R)
CHARGER	60	QL3051600200	Controller(PG S-140A)
CHARGER	73	QL3090432080	Cup bearing set
CHARGER	81	QLSJ04P129BG0	Battery fastener bracket
CHARGER	82	QLSE05A504A3A	Star knob(M8*45)
CHARGER	87	QLSG09E402AK0	Arm assembly(L)
CHARGER	87-1	QLWC09A409CA1	Arm pad(L/R)
CHARGER	88	QLWS37E004AK0-00	Seat assembly with swivel plate&slides
CHARGER	88-1	QLWS37E111AK0	Seat assembly only
CHARGER	88-1-1	QLWS34E113AK0	Head rest
CHARGER	88-1-2	QLWS34E201EK0	Hinge(L),angle-adjustable with handle
CHARGER	88-1-3	QLWS33E202FK0	Hinge(R)
CHARGER	88-2	QLSF03E412AK0	Seat swivel plate assembly
CHARGER	88-3	QLSE06E406BK0	Slide assembly(R)
CHARGER	88-4	QLSE06E407BK0	Slide assembly(L)
CHARGER	89	QLSG09E403AK0	Arm assembly(R)
CHARGER	90	QLSE01E402EK0	Seat post assembly
CHARGER	91	QLSL09E221BK0	Rear wheel assembly(air,13")(R)
CHARGER	91-1	QLSL09A219AG0	Rear hub(R)
CHARGER	91	QLSL09E236AK0	Rear wheel assembly(solid,13")(R)
CHARGER	92	QLZA15E106BK0	Drum brake assembly
CHARGER	94	QLSG03P172A3A	Drum brake mounting stopper
CHARGER	96	QLSL09A501B9D	Rear reflector with E-Mark(Red)
CHARGER	97	QLSL09P508B3A	Rear drivetrain cover
CHARGER	98	QLSL09E121AK0	N/A
CHARGER	98-1	QLRA13E111AK0	Transaxle assembly with motor and brake(1000W:CR-8065D24-A 21.06:1 8NM)
CHARGER	98-1-1	QLRA13A113AK0	Transaxle only(21.06:1)
CHARGER	98-1-2	QLRA13A308BK0	Motor only(CR-8065D24-A:1000W)(4 poles)
CHARGER	98-1-2-1	QL3051500110	Motor brush(CR-8065/95D24)
CHARGER	98-1-2-2	QL3051500170	Motor brush cap(CR-8065/95D24)
CHARGER	98-1-3	QLRA05A321AK0	EM brake only(24V 8NM)
CHARGER	98-1-4	QLRA05P137AG0	EM brake cover
CHARGER	98-1-5	QLRA13P106A3A	Coupling for transaxle

CHARGER	98-2	QLSL09A118A1F	Rear bumper
CHARGER	98-3	QLSK09P508A3A	D-like tube plug
CHARGER	98-4	QLSH05P170BG0	EM brake extension handle
CHARGER	98-5	QLSG06P515A4B	EM Brake handle cover(Yellow)
CHARGER	99	QLSL09E220BK0	Rear wheel assembly(air,13")(L) with speed sensing magnet
CHARGER	99-1	QLSL09A220AG0	Rear hub(L)
CHARGER	99-2	QLSK09A217B3A	speed sensing magnet
CHARGER	99	QLSL09E235AK0	Rear wheel assembly(solid,13")(L) with speed sensing magnet
CHARGER	102	QLSK09F608AK0	Speed sensor assembly with wire and connector
CHARGER	104	QLSF03F615AK0	Battery cable I
CHARGER	105	QLSF03F616AK0	Battery cable II
CHARGER	106	QLSL09F602AK0	Circuit breaker assembly with wire&connectors
CHARGER	107	QLSL09F607AK0	Harness assembly for turning lights
CHARGER	108	QLSL09F606AK0	Main harness assembly
CHARGER	108	QLSL09F611AK0	Main harness assembly-new version for stop lights
CHARGER	109	QL3052512110	Lead acid battery(12V75Ah)
CHARGER	110	QLSL09P801A2M	Anti-skid sticker(L) on the front deck
CHARGER	111	QLSL09P802A2M	Anti-skid sticker(R) on the front deck
CHARGER	117	QLSE06A510A3E	Key set(a pair)
CHARGER	118	QL3003700050	Rear mirror set(L&R)
CHARGER	119	QLZA15E201BK0	Manual brake handle assembly with braking light switch
CHARGER	120	QLSE07E505AK0	Mirror mounting bracket
CHARGER	121	QLSL09E201BK0	N/A
CHARGER	121-1	QLSK09A202AB4	Tiller delta handle
CHARGER	121-2	QLSE01A207BK0	Tiller shock
CHARGER	121-3	QLSF06A210B00	Cable for tiller shock
CHARGER	121-4	QLSF06P536A3A	Round tube plug
CHARGER	122	QLSL09E510AK0	N/A
CHARGER	122	QLSL09E510AK1	N/A
CHARGER	122-1	QLSL09F609AK0	Dashboard assembly(LCD)
CHARGER	122-1-1	QLSK09P519AP2	soft keyboard
CHARGER	122-1-2	QLSK09H603AN9	Keyboard PCB
CHARGER	122-1-3	QLSF06H610AN9	LCD screen&PCB assembly
CHARGER	122-1-4	QLSF03F611AK0	Key switch
CHARGER	122-1-5	QLSK09P518A4P	Top cover for LCD screen
CHARGER	122-1	QLSL09F613AK0	Dashboard assembly(LCD)-new version for stop lights
CHARGER	121-1-1	QLSL09H606AN9	LCD screen&PCB assembly-new version for stop lights
CHARGER	122-2	QLSF03F613AK0	Turning light assembly(F)
CHARGER	122-3	QLSL09E509AK9	Tiller top cover assembly with driving light
CHARGER	122-4	QLSF06P516AG1	Headlight reflecting base(R)(Silver)
CHARGER	122-5	QLSF06P517AG1	Headlight reflecting base(R)(Silver)
CHARGER	122-6	QLSF06P514A4V	Headlight cover(R)(Yellow)
CHARGER	122-7	QLSF06P515A4V	Headlight cover(L)(Yellow)
CHARGER	122-8	QLSL09P514D15	Tiller front cover only(Red 7645C)
CHARGER	122-9	QLSL09P514D03	Tiller front cover only(Blue 288C)
CHARGER	123	QLNA03P509A3A	Rubber plug
CHARGER	124	QLSL09P240AG0	Spacing column
CHARGER	127	QLSE08E508AK0	Basket with handle
CHARGER	128	QLSF03A225C00	Cable for manual brake
CHARGER	129	QLSE06P512E3A	Tiller boot
CHARGER	130	QLSL09E505AK0	Tiller rear cover assembly(Blue 288C)
CHARGER	130	QLSL09E505AK3	Tiller rear cover assembly(Red 7645C)
CHARGER	130-1	QLSL09P515B03	Tiller rear cover only(Blue 288C)
CHARGER	130-1	QLSL09P515B15	Tiller rear cover only(Red 7645C)
CHARGER	130-2	QLSK05F620AK4	USB Port
CHARGER	130-3	QLSF03F605AK0	Horn assembly in the tiller
CHARGER	130-4	QLSF03F604AK0	High-low switch
CHARGER	130-5	QLSF06F613CK0	Charging port on the tiller
CHARGER	131	QLSL09P522A3A	Plastic bracket for cup holders
CHARGER	134	QLSL09P521A3A	Tiller rear bottom cover
CHARGER	137	QLSJ05P507A3A	Cup holder(L)
CHARGER	139	QLSJ05P508A3A	Cup holder(R)
CHARGER	141	QLSG03F605AK0	Speed controll paddle assembly with potentiometer
CHARGER	144	QLSK09F614AK0	Turning speed-down sensor assembly
CHARGER	144	QLSK09F615AK0	Turning speed-down sensor assembly-new version for stop lights
CHARGER	N/A	QLEA02E906AK1	Charger(8A)