




|    |                |                                    |
|----|----------------|------------------------------------|
| 1  | HFDZKG0017     | Horn button                        |
| 2  | HFSLHS186C0901 | Panel label                        |
| 3  | HFWDZQT051     | Speed Controller RV24YN20SB104     |
| 4  | HFDZKG0018     | Potentiometer Knob RV24118010      |
| 5  | HFDZKG0021     | Key                                |
| 6  | HFDZKG0015     | Key Switch                         |
| 7  |                | Tiller Top cover                   |
| 10 | HFDZDX5103     | Digital Electricity Meter          |
| 11 | HFSLHS186C0903 | Panel Lower Cover ABS Black        |
| 12 | HFDZQT0133     | Fuse 5AMP                          |
| 16 | HFDZQT0096     | 3-Pin Charging Socket              |
| 18 | HFSLOHS4301501 | Throttle lever black               |
| 20 | HFB00480112301 | Buzzer PK-2IN30W DC24V HS480-11-23 |